

INSTALLATION INSTRUCTIONS FOR HANDLEBAR RISER PART NO. 2B003380

We recommend to protect the fuel tank before beginning with the installation.

- 1) Loosen (without removing) the screws fixing the original risers, placed under the upper fork plate.
- 2) Remove the 4 screws M8 fixing the handlebar.
- 3) Carefully arrange the "handlebar unit" on the previously protected tank.
- 4) Permanently remove the risers (lower) from the fork plate.
- 5) Position the cups included in the kit on the plate's rubber pads as illustrated in the photo.
- 6) Apply and fix the accessory riser (lower) using the original screws and washers M10 again. **Tightening torque 50Nm.**
- 7) Place the "handlebar unit" in the seat of the accessory riser (lower).
- 8) find the reference notches on the handlebar and correspondingly centre the accessory riser (lower).
- 9) Place and fix the riser (upper) using the original screws and washers M8 again. **Tightening torque 25Nm.**

WARNINGS AND PERIODIC CHECKS

After installation, check the correct rotation of the handlebar and rotation, contacts and operation of the cables.

After the first 500 km and periodically check the tightening torque of the screws.

