

## INSTALLATION MANUAL V4R Tuono 2011-

MRA-Klement GmbH + Siemens Str. 6 + D-79331 Teningen Tel.: +49 7663 9389 0 + Email: info@mra.de

Thank you for buying a MRA Windshield.

Read this manual carefully and check the parts list for completeness before you begin. We recommend that you have your screen fitted by an authorised workshop.

Parts List:	Required Tools:
<ul> <li>1 MRA screen</li> <li>1 edge protection strip</li> <li>2 clamp sleeves</li> </ul>	Allen key 3mm     Allen key 4mm
<ul> <li>Installation kit:</li> <li>2 fixing sheets</li> <li>3 rubber nuts, M5</li> <li>2 spacers, 15 mm</li> <li>2 screws, M 5 x 16</li> <li>1 screw, M 5 x 20</li> <li>2 screws, M 5 x 30</li> <li>3 plastic washers</li> <li>1 rubber spacer, 4 mm</li> </ul>	

- 1. Position the motorcycle on a level surface.
- 2. Unscrew the screw on the front of the windshield (P1).
- 3. Remove both screws on the fairing (P2). Lift the fairing from the locking mechanism and remove the windshield rearwards (P3).
- 4. Reposition the fairing into the locking mechanism and refasten both screws (P2).
- 5. Switch the original rubber nut (M4) with the M5 rubber nut (P4) provided.
- 6. Moisten the rubber nut for easy installation do not use grease or oil!
- 7. Install the fixing sheets included using the screws M 5 x 30 and the spacer 15mm (P4 + P5).
- 8. Put the two rubber nuts through the fixing sheets (P6).
- 9. Insert the screw M  $5 \times 20$  with the plastic washer in the front hole and position the rubber spacer on the screw from the inside.
- 10. Position the windshield and fix it with the pre-installed screw in front and both screws M 5 x 16 and plastic washers in the rear holes.
- 11. Check all screws for tightness.
- 12. Pull the edge protection profile onto the rear, exposed area of the windshield, beginning at the changeover of the fairing up to the opposite side. Cut the remaining part if necessary.
- 13. Place the clamp sleeves onto the ends of the edge protection profile and press them slightly using the flat nose pliers so that the edge protection profile is clamped.

After installation, check that all of the screws are tight; tighten them up if necessary. Repeat this at regular intervals. Clean the screen with water, neutral soap and a sponge. Do not use solvents, alcohol or spirits to clean the screen as they will damage it.

© by MRA-Klement GmbH - 05/2012

	,	
		8

