**V7 III ABS** 

## Scheduled maintenance table

CARRY OUT MAINTENANCE OPERATIONS AT HALF THE INTERVALS SPECIFIED IF THE VE-HICLE IS USED IN PARTICULAR RAINY OR DUSTY CONDITIONS, OFF ROAD OR FOR TRACK USE.

## NOTE

THE TIMES LISTED ON THE SCHEDULED MAINTENANCE TABLE INCLUDE TIME DEDICATED TO MANAGEMENT ACTIVITIES.

- I: INSPECT AND CLEAN, ADJUST, LUBRICATE OR REPLACE IF NECESSARY
- C: CLEAN, R: REPLACE, A: ADJUST, L: LUBRICATE
- (1): Replace in case of leakage
- (2): Replace every 4 years
- (3): At each engine start
- (4): Check every month
- (5): Check every 5,000 km (3,106 mi)

Km x 1,000 (mi x 1,000)

- (6): Check and clean, adjust or replace, if necessary, every 1,000 Km (621 mi)
- (7): Replace at whichever of the following occurs first: 40,000 km (24,855 mi) or 4 years

1,5 10

(8): At each service (except the first one), check inside the filter box, if there is oil. In this case, clean it

## SCHEDULED MAINTENANCE TABLE 20

30

40 50 60 EVERY EVERY

Kill X 1,000 (illi X 1,000)	(0.9)	(6.2)	(12.4)	(18.6)	(24.9)	(31.1)	(37.3)	12 MONTH S	24 MONTH S
Spark plugs		R	R	R	R	R	R		
Filter box (8)		С	С	С	С	С	С		
Transmission cables and controls	1	1	1	1	1	1	1	1	1
Steering bearings and steering clearance		1	1	1	- 1	1	1	1 .	
Wheel bearings - Wheels	1	1	1	1	1	1	1	1	-1-1
Diagnosis by tool	1	1	1	1	1	1	1	1	1
Brake discs - Brake pads wear (6)	1	- 1	1	- 1	- 1	1	1	1	1
Air filter		R	R	R	R	R	R		
Oil filter change	С						С		
Engine oil filter	R	R	R	R	R	R	R	R	R
Vehicle general operation	1	1		1	1	1	1	la de la composición della com	Land behalf
Valve clearance	Α	Α	Α	Α	Α	Α	Α		
Braking systems	- 1	1	1	1	1	1	1	1	1
Light circuit	1	1	1	1	1	1	1	1	1
Safety switches	1	1.0	1	1	1	1	1	1	1
Brake fluid			1	1	1	1	1	1	R
Gearbox oil	R						R		
Fork oil (7)					R				
Engine oil (5)	R	R	R	R	R	R	R	R	R
Final drive oil			R		R		R	R	R
Headlight aiming		1		1		1	1		
Fork oil seals (1)	1	1	1	1			1		
Tyres - pressure / wear (4)	1	1	1	1	1	1	1	1	1 1
Clutch clearance adjustment	1	1	I		*		1		
Bolts and nuts tightening	1	1	1	1	1	1	1		
Battery terminals tightening	1								1
Suspensions and setting			1		1			1	1
Engine oil pressure warning light (3)									
Filter box drain plug	С	С	С	С	С	©	С	С	С
Brake pipes		1	1			1	1		

Km x 1,000 (mi x 1,000) *	1,5 (0.9)	10 (6.2)	20 (12.4)	30 (18.6)	40 (24.9)	50 (31.1)	60 (37.3)	EVERY 12 MONTH S	EVERY 24 MONTH S
Fuel lines (2)		1	1	-1	1	1	1	1	1
Clutch wear	э.	1	1	1			1		
Labour time (minutes)	80	90	90	90	120	90	100	60	60